

## ROTISSERIE INSTRUCTIONS

### STEP 1

Remove all components from the carton.

### STEP 2

Put the circular base upon the grill and turn the highest part in face of user.

### STEP 3

Slide a skewer fork onto each end of spit rod and tighten the thumb screw to secure the skewer forks in place. Slide the collar onto the threaded end of the spit rod. Do not tighten the collar thumb screw of the collar until the rotisserie is placed into position in the barbecue. Tighten all thumb screws to prevent loosening during cooking process.

### STEP 4

Install the motor to the motor bracket. Push the end of the spit rod into the opening of the motor until fully in position.

